


Ausbau der Tastatur

Please remove the battery.



remove the screw from the location marked K/B on the underside of the system






Release all 6 latches of the keyboard
(please use something like the plastic tool to avoid damage and scratching)

after unlock the latches you can lift the keyboard and turn it over without releasing the cable.



RAM Module
cover - held
down by tape



Insert RAM module
at an angle
and clip down



Screw